

Vol
1.4

Generated by Doxygen 1.7.1

Mon Nov 25 2013 17:37:35

Contents

1 Class Index	1
1.1 Class Hierarchy	1
2 Class Index	2
2.1 Class List	2
3 Class Documentation	3
3.1 OsiVolSolverInterface Class Reference	3
3.1.1 Detailed Description	12
3.1.2 Member Function Documentation	12
3.1.3 Friends And Related Function Documentation	20
3.2 VOL_alpha_factor Class Reference	20
3.2.1 Detailed Description	20
3.3 VOL_dual Class Reference	21
3.3.1 Detailed Description	21
3.4 VOL_dvector Class Reference	21
3.4.1 Detailed Description	23
3.4.2 Constructor & Destructor Documentation	23
3.4.3 Member Function Documentation	24
3.5 VOL_indc Class Reference	25
3.5.1 Detailed Description	25
3.6 VOL_ivector Class Reference	25
3.6.1 Detailed Description	27
3.6.2 Constructor & Destructor Documentation	27
3.6.3 Member Function Documentation	28
3.6.4 Member Data Documentation	29
3.7 VOL_parms Struct Reference	30
3.7.1 Detailed Description	31
3.7.2 Member Data Documentation	31
3.8 VOL_primal Class Reference	32

3.8.1	Detailed Description	32
3.9	VOL_problem Class Reference	33
3.9.1	Detailed Description	35
3.9.2	Constructor & Destructor Documentation	35
3.9.3	Member Function Documentation	35
3.10	VOL_swing Class Reference	36
3.10.1	Detailed Description	36
3.11	VOL_user_hooks Class Reference	36
3.11.1	Detailed Description	37
3.11.2	Member Function Documentation	37
3.12	VOL_vh Class Reference	38
3.12.1	Detailed Description	38

1 Class Index

1.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

```
std::basic_fstream< char >
std::basic_fstream< wchar_t >
std::basic_ifstream< char >
std::basic_ifstream< wchar_t >
std::basic_ios< char >
std::basic_ios< wchar_t >
std::basic_iostream< char >
std::basic_iostream< wchar_t >
std::basic_istream< char >
std::basic_istream< wchar_t >
std::basic_istringstream< char >
std::basic_istringstream< wchar_t >
std::basic_ofstream< char >
std::basic_ofstream< wchar_t >
std::basic_ostream< char >
std::basic_ostream< wchar_t >
std::basic_ostringstream< char >
std::basic_ostringstream< wchar_t >
std::basic_string< char >
std::basic_string< wchar_t >
```

std::basic_ostream< char >	
std::basic_ostream< wchar_t >	
VOL_alpha_factor	20
VOL_dual	21
VOL_dvector	21
VOL_indc	25
VOL_ivector	25
VOL_parms	30
VOL_primal	32
VOL_problem	33
VOL_swing	36
VOL_user_hooks	36
OsiVolSolverInterface	3
VOL_vh	38

2 Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

OsiVolSolverInterface (Vol(ume) Solver Interface)	3
VOL_alpha_factor	20
VOL_dual	21
VOL_dvector (Vector of doubles)	21
VOL_indc	25
VOL_ivector (Vector of ints)	25
VOL_parms (This class contains the parameters controlling the Volume Algorithm)	30

VOL_primal	32
VOL_problem (This class holds every data for the Volume Algorithm and its <code>solve</code> method must be invoked to solve the problem)	33
VOL_swing	36
VOL_user_hooks (The user hooks should be overridden by the user to provide the problem specific routines for the volume algorithm)	36
VOL_vh	38


3 Class Documentation

3.1 OsiVolSolverInterface Class Reference


Vol(ume) Solver Interface.

```
#include <OsiVolSolverInterface.hpp>
```

Inheritance diagram for OsiVolSolverInterface:



Collaboration diagram for OsiVolSolverInterface:



Classes

- class **OsiVolMatrixOneMinusOne**

Public Member Functions

- virtual void **setObjSense** (double s)
Set objective function sense (1 for min (default), -1 for max,).
 - virtual void **setColSolution** (const double *colsol)
Set the primal solution column values.
 - virtual void **setRowPrice** (const double *rowprice)
Set dual solution vector.

Solve methods

- virtual void `initialSolve()`
 $Solve$ initial LP relaxation.

- virtual void **resolve** ()

Resolve an LP relaxation after problem modification.
- virtual void **branchAndBound** ()

Invoke solver's built-in enumeration algorithm.

Parameter set/get methods

The set methods return true if the parameter was set to the given value, false otherwise.

There can be various reasons for failure: the given parameter is not applicable for the solver (e.g., refactorization frequency for the volume algorithm), the parameter is not yet implemented for the solver or simply the value of the parameter is out of the range the solver accepts. If a parameter setting call returns false check the details of your solver.

The get methods return true if the given parameter is applicable for the solver and is implemented. In this case the value of the parameter is returned in the second argument. Otherwise they return false.

- bool **setIntParam** (OsiIntParam key, int value)
- bool **setDblParam** (OsiDblParam key, double value)
- bool **setStrParam** (OsiStrParam key, const std::string &value)
- bool **getIntParam** (OsiIntParam key, int &value) const
- bool **getDblParam** (OsiDblParam key, double &value) const
- bool **getStrParam** (OsiStrParam key, std::string &value) const

Methods returning info on how the solution process terminated

- virtual bool **isAbandoned** () const

Are there any numerical difficulties?
- virtual bool **isProvenOptimal** () const

Is optimality proven?
- virtual bool **isProvenPrimalInfeasible** () const

Is primal infeasibility proven?
- virtual bool **isProvenDualInfeasible** () const

Is dual infeasibility proven?
- virtual bool **isPrimalObjectiveLimitReached** () const

Is the given primal objective limit reached?
- virtual bool **isDualObjectiveLimitReached** () const

Is the given dual objective limit reached?

- virtual bool [isIterationLimitReached \(\) const](#)
Iteration limit reached?

WarmStart related methods

- virtual CoinWarmStart * [getEmptyWarmStart \(\) const](#)
Get an empty warm start object.
- virtual CoinWarmStart * [getWarmStart \(\) const](#)
Get warmstarting information.
- virtual bool [setWarmStart \(const CoinWarmStart *warmstart\)](#)
Set warmstarting information.

Hotstart related methods (primarily used in strong branching).

The user can create a hotstart (a snapshot) of the optimization process then reoptimize over and over again always starting from there.

NOTE: between hotstarted optimizations only bound changes are allowed.

- virtual void [markHotStart \(\)](#)
Create a hotstart point of the optimization process.
- virtual void [solveFromHotStart \(\)](#)
Optimize starting from the hotstart.
- virtual void [unmarkHotStart \(\)](#)
Delete the snapshot.

Methods related to querying the input data

- virtual int [getNumCols \(\) const](#)
Get number of columns.
- virtual int [getNumRows \(\) const](#)
Get number of rows.
- virtual int [getNumElements \(\) const](#)
Get number of nonzero elements.
- virtual const double * [getColLower \(\) const](#)
Get pointer to array[[getNumCols\(\)](#)] of column lower bounds.

- virtual const double * [getColUpper](#) () const
Get pointer to array[getNumCols()] of column upper bounds.
- virtual const char * [getRowSense](#) () const
Get pointer to array[getNumRows()] of row constraint senses.
- virtual const double * [getRightHandSide](#) () const
Get pointer to array[getNumRows()] of rows right-hand sides.
- virtual const double * [getRowRange](#) () const
Get pointer to array[getNumRows()] of row ranges.
- virtual const double * [getRowLower](#) () const
Get pointer to array[getNumRows()] of row lower bounds.
- virtual const double * [getRowUpper](#) () const
Get pointer to array[getNumRows()] of row upper bounds.
- virtual const double * [getObjCoefficients](#) () const
Get pointer to array[getNumCols()] of objective function coefficients.
- virtual double [getObjSense](#) () const
Get objective function sense (1 for min (default), -1 for max).
- virtual bool [isContinuous](#) (int colNumber) const
Return true if column is continuous.
- virtual const CoinPackedMatrix * [getMatrixByRow](#) () const
Get pointer to row-wise copy of matrix.
- virtual const CoinPackedMatrix * [getMatrixByCol](#) () const
Get pointer to column-wise copy of matrix.
- virtual double [getInfinity](#) () const
Get solver's value for infinity.

Methods related to querying the solution

- virtual const double * [getColSolution](#) () const
Get pointer to array[getNumCols()] of primal solution vector.
- virtual const double * [getRowPrice](#) () const
Get pointer to array[getNumRows()] of dual prices.

- virtual const double * `getReducedCost` () const
Get a pointer to array[`getNumCols()`] of reduced costs.
- virtual const double * `getRowActivity` () const
Get pointer to array[`getNumRows()`] of row activity levels (constraint matrix times the solution vector).
- virtual double `getObjValue` () const
Get objective function value.
- virtual int `getIterationCount` () const
Get how many iterations it took to solve the problem (whatever "iteration" mean to the solver).
- virtual std::vector< double * > `getDualRays` (int maxNumRays, bool fullRay=false) const
Get as many dual rays as the solver can provide.
- virtual std::vector< double * > `getPrimalRays` (int maxNumRays) const
Get as many primal rays as the solver can provide.

Changing bounds on variables and constraints

- virtual void `setObjCoeff` (int elementIndex, double elementValue)
Set an objective function coefficient.
- virtual void `setColLower` (int elementIndex, double elementValue)
Set a single column lower bound
Use -DBL_MAX for -infinity.
- virtual void `setColUpper` (int elementIndex, double elementValue)
Set a single column upper bound
Use DBL_MAX for infinity.
- virtual void `setColBounds` (int elementIndex, double lower, double upper)
Set a single column lower and upper bound.
- virtual void `setColSetBounds` (const int *indexFirst, const int *indexLast, const double *boundList)
Set the bounds on a number of columns simultaneously
The default implementation just invokes `setColLower()` and `setColUpper()` over and over again.
- virtual void `setRowLower` (int elementIndex, double elementValue)
Set a single row lower bound
Use -DBL_MAX for -infinity.

- virtual void [setRowUpper](#) (int elementIndex, double elementValue)
*Set a single row upper bound
Use DBL_MAX for infinity.*
- virtual void [setRowBounds](#) (int elementIndex, double lower, double upper)
Set a single row lower and upper bound.
- virtual void [setRowType](#) (int index, char sense, double rightHandSide, double range)
Set the type of a single row
- virtual void [setRowSetBounds](#) (const int *indexFirst, const int *indexLast, const double *boundList)
*Set the bounds on a number of rows simultaneously
The default implementation just invokes [setRowLower\(\)](#) and [setRowUpper\(\)](#) over and over again.*
- virtual void [setRowSetTypes](#) (const int *indexFirst, const int *indexLast, const char *senseList, const double *rhsList, const double *rangeList)
*Set the type of a number of rows simultaneously
The default implementation just invokes [setRowType\(\)](#) over and over again.*

Integrality related changing methods

- virtual void [setContinuous](#) (int index)
Set the index-th variable to be a continuous variable.
- virtual void [setInteger](#) (int index)
Set the index-th variable to be an integer variable.
- virtual void [setContinuous](#) (const int *indices, int len)
Set the variables listed in indices (which is of length len) to be continuous variables.
- virtual void [setInteger](#) (const int *indices, int len)
Set the variables listed in indices (which is of length len) to be integer variables.

Methods to expand a problem.

Note that if a column is added then by default it will correspond to a continuous variable.

- virtual void [addCol](#) (const CoinPackedVectorBase &vec, const double collb, const double colub, const double obj)

- virtual void **addCols** (const int numcols, const CoinPackedVectorBase *const *cols, const double *collb, const double *colub, const double *obj)
- virtual void **deleteCols** (const int num, const int *colIndices)
- virtual void **addRow** (const CoinPackedVectorBase &vec, const double rowlb, const double rowub)
- virtual void **addRow** (const CoinPackedVectorBase &vec, const char rowsen, const double rowrhs, const double rowrng)
- virtual void **addRows** (const int numrows, const CoinPackedVectorBase *const *rows, const double *rowlb, const double *rowub)
- virtual void **addRows** (const int numrows, const CoinPackedVectorBase *const *rows, const char *rowsen, const double *rowrhs, const double *rowrng)
- virtual void **deleteRows** (const int num, const int *rowIndices)

Methods to input a problem

- virtual void **loadProblem** (const CoinPackedMatrix &matrix, const double *collb, const double *colub, const double *obj, const double *rowlb, const double *rowub)

Load in an problem by copying the arguments (the constraints on the rows are given by lower and upper bounds).
- virtual void **assignProblem** (CoinPackedMatrix *&matrix, double *&collb, double *&colub, double *&obj, double *&rowlb, double *&rowub)

Load in an problem by assuming ownership of the arguments (the constraints on the rows are given by lower and upper bounds).
- virtual void **loadProblem** (const CoinPackedMatrix &matrix, const double *collb, const double *colub, const double *obj, const char *rowsen, const double *rowrhs, const double *rowrng)

Load in an problem by copying the arguments (the constraints on the rows are given by sense/rhs/range triplets).
- virtual void **assignProblem** (CoinPackedMatrix *&matrix, double *&collb, double *&colub, double *&obj, char *&rowsen, double *&rowrhs, double *&rowrng)

Load in an problem by assuming ownership of the arguments (the constraints on the rows are given by sense/rhs/range triplets).
- virtual void **loadProblem** (const int numcols, const int numrows, const int *start, const int *index, const double *value, const double *collb, const double *colub, const double *obj, const double *rowlb, const double *rowub)

Just like the other `loadProblem()` methods except that the matrix is given in a standard column major ordered format (without gaps).
- virtual void **loadProblem** (const int numcols, const int numrows, const int *start, const int *index, const double *value, const double *collb, const double

*colub, const double *obj, const char *rowsen, const double *rowrhs, const double *rowrng)

Just like the other [loadProblem\(\)](#) methods except that the matrix is given in a standard column major ordered format (without gaps).

- virtual int [readMps](#) (const char *filename, const char *extension="mps")
Read an mps file from the given filename.
- virtual void [writeMps](#) (const char *filename, const char *extension="mps", double objSense=0.0) const
Write the problem into an mps file of the given filename.

OSL specific public interfaces

- [VOL_problem * volprob](#) ()
Get pointer to Vol model.

Constructors and destructors

- [OsiVolSolverInterface](#) ()
Default Constructor.
- virtual OsiSolverInterface * [clone](#) (bool copyData=true) const
Clone.
- [OsiVolSolverInterface](#) (const [OsiVolSolverInterface](#) &)
Copy constructor.
- [OsiVolSolverInterface & operator=](#) (const [OsiVolSolverInterface](#) &rhs)
Assignment operator.
- virtual [~OsiVolSolverInterface](#) ()
Destructor.

Protected Member Functions

Helper methods for problem input

- void [initFromRlbRub](#) (const int rownum, const double *rowlb, const double *rowub)
- void [initFromRhsSenseRange](#) (const int rownum, const char *rowsen, const double *rowrhs, const double *rowrng)

- void **initFromClbCubObj** (const int colnum, const double *collb, const double *colub, const double *obj)

Protected methods

- virtual void **applyRowCut** (const OsiRowCut &rc)
Apply a row cut (append to constraint matrix).
- virtual void **applyColCut** (const OsiColCut &cc)
Apply a column cut (adjust one or more bounds).

Friends

- void **OsiVolSolverInterfaceUnitTest** (const std::string &mpsDir, const std::string &netlibDir)
A function that tests the methods in the [OsiVolSolverInterface](#) class.

3.1.1 Detailed Description

Vol(ume) Solver Interface. Instantiation of [OsiVolSolverInterface](#) for the Volume Algorithm

Definition at line 27 of file OsiVolSolverInterface.hpp.

3.1.2 Member Function Documentation

3.1.2.1 virtual CoinWarmStart* OsiVolSolverInterface::getEmptyWarmStart () const [virtual]

Get an empty warm start object.

This routine returns an empty warm start object. Its purpose is to provide a way to give a client a warm start object of the appropriate type, which can be resized and modified as desired.

3.1.2.2 virtual bool OsiVolSolverInterface::setWarmStart (const CoinWarmStart * *warmstart*) [virtual]

Set warmstarting information.

Return true/false depending on whether the warmstart information was accepted or not.

3.1.2.3 **virtual const char* OsiVolSolverInterface::getRowSense () const [inline, virtual]**

Get pointer to array[getNumRows())] of row constraint senses.

- 'L' <= constraint
- 'E' = constraint
- 'G' >= constraint
- 'R' ranged constraint
- 'N' free constraint

Definition at line 196 of file OsiVolSolverInterface.hpp.

3.1.2.4 **virtual const double* OsiVolSolverInterface::getRightHandSide () const [inline, virtual]**

Get pointer to array[getNumRows())] of rows right-hand sides.

- if rowsense()[i] == 'L' then rhs()[i] == rowupper()[i]
- if rowsense()[i] == 'G' then rhs()[i] == rowlower()[i]
- if rowsense()[i] == 'R' then rhs()[i] == rowupper()[i]
- if rowsense()[i] == 'N' then rhs()[i] == 0.0

Definition at line 206 of file OsiVolSolverInterface.hpp.

3.1.2.5 **virtual const double* OsiVolSolverInterface::getRowRange () const [inline, virtual]**

Get pointer to array[getNumRows())] of row ranges.

- if rowsense()[i] == 'R' then rowrange()[i] == rowupper()[i] - rowlower()[i]

- if rowsense()[i] != 'R' then rowrange()[i] is undefined

Definition at line 216 of file OsiVolSolverInterface.hpp.

3.1.2.6 `virtual int OsiVolSolverInterface::getIterationCount () const [inline, virtual]`

Get how many iterations it took to solve the problem (whatever "iteration" mean to the solver.

Definition at line 287 of file OsiVolSolverInterface.hpp.

3.1.2.7 `virtual std::vector<double*> OsiVolSolverInterface::getDualRays (int maxNumRays, bool fullRay = false) const [virtual]`

Get as many dual rays as the solver can provide.

(In case of proven primal infeasibility there should be at least one.)

The first `getNumRows()` ray components will always be associated with the row duals (as returned by `getRowPrice()`). If `fullRay` is true, the final `getNumCols()` entries will correspond to the ray components associated with the nonbasic variables. If the full ray is requested and the method cannot provide it, it will throw an exception.

NOTE for implementers of solver interfaces:

The double pointers in the vector should point to arrays of length `getNumRows()` and they should be allocated via `new[]`.

NOTE for users of solver interfaces:

It is the user's responsibility to free the double pointers in the vector using `delete[]`.

3.1.2.8 `virtual std::vector<double*> OsiVolSolverInterface::getPrimalRays (int maxNumRays) const [virtual]`

Get as many primal rays as the solver can provide.

(In case of proven dual infeasibility there should be at least one.)

NOTE for implementers of solver interfaces:

The double pointers in the vector should point to arrays of length `getNumCols()` and they should be allocated via `new[]`.

NOTE for users of solver interfaces:

It is the user's responsibility to free the double pointers in the vector using `delete[]`.

**3.1.2.9 `virtual void OsiVolSolverInterface::setColLower (int elementIndex,
double elementValue) [inline, virtual]`**

Set a single column lower bound

Use `-DBL_MAX` for -infinity.

Definition at line 345 of file `OsiVolSolverInterface.hpp`.

**3.1.2.10 `virtual void OsiVolSolverInterface::setColUpper (int elementIndex,
double elementValue) [inline, virtual]`**

Set a single column upper bound

Use `DBL_MAX` for infinity.

Definition at line 352 of file `OsiVolSolverInterface.hpp`.

**3.1.2.11 `virtual void OsiVolSolverInterface::setColSetBounds (const int *
indexFirst, const int * indexLast, const double * boundList)
[virtual]`**

Set the bounds on a number of columns simultaneously

The default implementation just invokes `setColLower()` and `setColUpper()` over and over again.

Parameters

indexFirst,*indexLast* pointers to the beginning and after the end of the array of the indices of the variables whose *either* bound changes

boundList the new lower/upper bound pairs for the variables

**3.1.2.12 `virtual void OsiVolSolverInterface::setRowLower (int elementIndex,
double elementValue) [inline, virtual]`**

Set a single row lower bound

Use -DBL_MAX for -infinity.

Definition at line 377 of file OsiVolSolverInterface.hpp.

3.1.2.13 virtual void OsiVolSolverInterface::setRowLower (int *elementIndex*, double *elementValue*) [inline, virtual]

Set a single row upper bound

Use DBL_MAX for infinity.

Definition at line 386 of file OsiVolSolverInterface.hpp.

3.1.2.14 virtual void OsiVolSolverInterface::setRowSetBounds (const int * *indexFirst*, const int * *indexLast*, const double * *boundList*) [virtual]

Set the bounds on a number of rows simultaneously

The default implementation just invokes [setRowLower\(\)](#) and [setRowUpper\(\)](#) over and over again.

Parameters

indexFirst,*indexLast* pointers to the beginning and after the end of the array of
the indices of the constraints whose *either* bound changes
boundList the new lower/upper bound pairs for the constraints

3.1.2.15 virtual void OsiVolSolverInterface::setRowSetTypes (const int * *indexFirst*, const int * *indexLast*, const char * *senseList*, const double * *rhsList*, const double * *rangeList*) [virtual]

Set the type of a number of rows simultaneously

The default implementation just invokes [setRowType\(\)](#) over and over again.

Parameters

indexFirst,*indexLast* pointers to the beginning and after the end of the array of
the indices of the constraints whose *any* characteristics changes

senseList the new senses

rhsList the new right hand sides

rangeList the new ranges

3.1.2.16 virtual void OsiVolSolverInterface::setColSolution (const double * *colsol*) [virtual]

Set the primal solution column values.

colsol[numcols()] is an array of values of the problem column variables. These values are copied to memory owned by the solver object or the solver. They will be returned as the result of *colsol*() until changed by another call to *setColsol*() or by a call to any solver routine. Whether the solver makes use of the solution in any way is solver-dependent.

3.1.2.17 virtual void OsiVolSolverInterface::setRowPrice (const double * *rowprice*) [virtual]

Set dual solution vector.

rowprice[numrows()] is an array of values of the problem row dual variables. These values are copied to memory owned by the solver object or the solver. They will be returned as the result of *rowprice*() until changed by another call to *setRowprice*() or by a call to any solver routine. Whether the solver makes use of the solution in any way is solver-dependent.

3.1.2.18 virtual void OsiVolSolverInterface::loadProblem (const CoinPackedMatrix & *matrix*, const double * *collb*, const double * *colub*, const double * *obj*, const double * *rowlb*, const double * *rowub*) [virtual]

Load in an problem by copying the arguments (the constraints on the rows are given by lower and upper bounds).

If a pointer is 0 then the following values are the default:

- *colub*: all columns have upper bound infinity
- *collb*: all columns have lower bound 0

- `rowub`: all rows have upper bound infinity
- `rowlb`: all rows have lower bound -infinity
- `obj`: all variables have 0 objective coefficient

3.1.2.19 `virtual void OsiVolSolverInterface::assignProblem (CoinPackedMatrix *& matrix, double *& collb, double *& colub, double *& obj, double *& rowlb, double *& rowub) [virtual]`

Load in an problem by assuming ownership of the arguments (the constraints on the rows are given by lower and upper bounds).

For default values see the previous method.

WARNING: The arguments passed to this method will be freed using the C++ `delete` and `delete[]` functions.

3.1.2.20 `virtual void OsiVolSolverInterface::loadProblem (const CoinPackedMatrix & matrix, const double * collb, const double * colub, const double * obj, const char * rowsen, const double * rowrhs, const double * rowrng) [virtual]`

Load in an problem by copying the arguments (the constraints on the rows are given by sense/rhs/range triplets).

If a pointer is 0 then the following values are the default:

- `colub`: all columns have upper bound infinity
- `collb`: all columns have lower bound 0
- `obj`: all variables have 0 objective coefficient
- `rowsen`: all rows are \geq
- `rowrhs`: all right hand sides are 0
- `rowrng`: 0 for the ranged rows

3.1.2.21 `virtual void OsiVolSolverInterface::assignProblem (CoinPackedMatrix *& matrix, double *& collb, double *& colub, double *& obj, char *& rowsen, double *& rowrhs, double *& rowrng) [virtual]`

Load in an problem by assuming ownership of the arguments (the constraints on the rows are given by sense/rhs/range triplets).

For default values see the previous method.

WARNING: The arguments passed to this method will be freed using the C++ `delete` and `delete[]` functions.

3.1.2.22 `virtual void OsiVolSolverInterface::loadProblem (const int numcols, const int numrows, const int * start, const int * index, const double * value, const double * collb, const double * colub, const double * obj, const double * rowlb, const double * rowub) [virtual]`

Just like the other `loadProblem()` methods except that the matrix is given in a standard column major ordered format (without gaps).

3.1.2.23 `virtual void OsiVolSolverInterface::loadProblem (const int numcols, const int numrows, const int * start, const int * index, const double * value, const double * collb, const double * colub, const double * obj, const char * rowsen, const double * rowrhs, const double * rowrng) [virtual]`

Just like the other `loadProblem()` methods except that the matrix is given in a standard column major ordered format (without gaps).

3.1.2.24 `virtual void OsiVolSolverInterface::writeMps (const char * filename, const char * extension = "mps", double objSense = 0.0) const [virtual]`

Write the problem into an mps file of the given filename.

If `objSense` is non zero then -1.0 forces the code to write a maximization objective and +1.0 to write a minimization one. If 0.0 then solver can do what it wants

3.1.2.25 virtual void OsiVolSolverInterface::applyRowCut (const OsiRowCut & *rc*) [protected, virtual]

Apply a row cut (append to constraint matrix).

3.1.2.26 virtual void OsiVolSolverInterface::applyColCut (const OsiColCut & *cc*) [protected, virtual]

Apply a column cut (adjust one or more bounds).

3.1.3 Friends And Related Function Documentation

3.1.3.1 void OsiVolSolverInterfaceUnitTest (const std::string & *mpsDir*, const std::string & *netlibDir*) [friend]

A function that tests the methods in the [OsiVolSolverInterface](#) class.

The documentation for this class was generated from the following file:

- OsiVolSolverInterface.hpp

3.2 VOL_alpha_factor Class Reference

3.2.1 Detailed Description


Definition at line 489 of file VolVolume.hpp.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.3 VOL_dual Class Reference

Collaboration diagram for VOL_dual:



3.3.1 Detailed Description

Definition at line 354 of file VolVolume.hpp.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.4 VOL_dvector Class Reference

vector of doubles.

```
#include <VolVolume.hpp>
```

Public Member Functions

- **VOL_dvector** (const int s)
Construct a vector of size s.
- **VOL_dvector** ()
Default constructor creates a vector of size 0.
- **VOL_dvector** (const VOL_dvector &x)

Copy constructor makes a replica of x.

- `~VOL_dvector ()`

The destructor deletes the data array.

- `int size () const`

Return the size of the vector.

- `double & operator[] (const int i)`

*Return a reference to the *i*-th entry.*

- `double operator[] (const int i) const`

*Return the *i*-th entry.*

- `void clear ()`

Delete the content of the vector and replace it with a vector of length 0.

- `void cc (const double gamma, const VOL_dvector &w)`

Convex combination.

- `void allocate (const int s)`

*delete the current vector and allocate space for a vector of size *s*.*

- `void swap (VOL_dvector &w)`

*swaps the vector with *w*.*

- `VOL_dvector & operator= (const VOL_dvector &w)`

*Copy *w* into the vector.*

- `VOL_dvector & operator= (const double w)`

*Replace every entry in the vector with *w*.*

Public Attributes

- `double * v`

The array holding the vector.

- `int sz`

The size of the vector.

3.4.1 Detailed Description

vector of doubles. It is used for most vector operations.

Note: If VOL_DEBUG is defined to be 1 then each time an entry is accessed in the vector the index of the entry is tested for nonnegativity and for being less than the size of the vector. It's good to turn this on while debugging, but in final runs it should be turned off (because of the performance hit).

Definition at line 148 of file VolVolume.hpp.

3.4.2 Constructor & Destructor Documentation

3.4.2.1 VOL_dvector::VOL_dvector (const int s) [inline]

Construct a vector of size s.

The content of the vector is undefined.

Definition at line 157 of file VolVolume.hpp.

3.4.2.2 VOL_dvector::VOL_dvector () [inline]

Default constructor creates a vector of size 0.

Definition at line 162 of file VolVolume.hpp.

3.4.2.3 VOL_dvector::VOL_dvector (const VOL_dvector & x) [inline]

Copy constructor makes a replica of x.

Definition at line 164 of file VolVolume.hpp.

3.4.2.4 VOL_dvector::~VOL_dvector () [inline]

The destructor deletes the data array.

Definition at line 172 of file VolVolume.hpp.

3.4.3 Member Function Documentation

3.4.3.1 int VOL_dvector::size () const [inline]

Return the size of the vector.

Definition at line 175 of file VolVolume.hpp.

3.4.3.2 double& VOL_dvector::operator[](const int *i*) [inline]

Return a reference to the *i*-th entry.

Definition at line 178 of file VolVolume.hpp.

3.4.3.3 double VOL_dvector::operator[](const int *i*) const [inline]

Return the *i*-th entry.

Definition at line 184 of file VolVolume.hpp.

3.4.3.4 void VOL_dvector::clear () [inline]

Delete the content of the vector and replace it with a vector of length 0.

Definition at line 191 of file VolVolume.hpp.

3.4.3.5 void VOL_dvector::cc (const double *gamma*, const VOL_dvector & *w*) [inline]

Convex combination.

Replace the current vector *v* with *v* = (1-*gamma*) *v* + *gamma* *w*.

Definition at line 198 of file VolVolume.hpp.

3.4.3.6 void VOL_dvector::allocate (const int *s*) [inline]

delete the current vector and allocate space for a vector of size s.

Definition at line 214 of file VolVolume.hpp.

3.4.3.7 void VOL_dvector::swap (VOL_dvector & w) [inline]

swaps the vector with w.

Definition at line 221 of file VolVolume.hpp.

3.4.3.8 VOL_dvector& VOL_dvector::operator= (const VOL_dvector & w)

Copy w into the vector.

3.4.3.9 VOL_dvector& VOL_dvector::operator= (const double w)

Replace every entry in the vector with w.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.5 VOL_indc Class Reference

3.5.1 Detailed Description

Definition at line 538 of file VolVolume.hpp.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.6 VOL_ivector Class Reference

vector of ints.

```
#include <VolVolume.hpp>
```

Public Member Functions

- **VOL_ivector** (const int s)
Construct a vector of size s.
- **VOL_ivector** ()
Default constructor creates a vector of size 0.
- **VOL_ivector** (const VOL_ivector &x)
Copy constructor makes a replica of x.
- **~VOL_ivector** ()
The destructor deletes the data array.
- int **size** () const
Return the size of the vector.
- int & **operator[]** (const int i)
*Return a reference to the *i*-th entry.*
- int **operator[]** (const int i) const
*Return the *i*-th entry.*
- void **clear** ()
Delete the content of the vector and replace it with a vector of length 0.
- void **allocate** (const int s)
delete the current vector and allocate space for a vector of size s.
- void **swap** (VOL_ivector &w)
swaps the vector with w.
- **VOL_ivector & operator=** (const VOL_ivector &v)
Copy v into the vector.
- **VOL_ivector & operator=** (const int w)
Replace every entry in the vector with w.

Public Attributes

- int * **v**

The array holding the vector.

- int **sz**

The size of the vector.

3.6.1 Detailed Description

vector of ints. It's used to store indices, it has similar functions as [VOL_dvector](#).

Note: If VOL_DEBUG is defined to be 1 then each time an entry is accessed in the vector the index of the entry is tested for nonnegativity and for being less than the size of the vector. It's good to turn this on while debugging, but in final runs it should be turned off (because of the performance hit).

Definition at line 242 of file VolVolume.hpp.

3.6.2 Constructor & Destructor Documentation

3.6.2.1 VOL_ivector::VOL_ivector (const int s) [inline]

Construct a vector of size s.

The content of the vector is undefined.

Definition at line 250 of file VolVolume.hpp.

3.6.2.2 VOL_ivector::VOL_ivector () [inline]

Default constructor creates a vector of size 0.

Definition at line 255 of file VolVolume.hpp.

3.6.2.3 VOL_ivector::VOL_ivector (const VOL_ivector & x) [inline]

Copy constructor makes a replica of x.

Definition at line 257 of file VolVolume.hpp.

3.6.2.4 VOL_ivector::~VOL_ivector() [inline]

The destructor deletes the data array.

Definition at line 265 of file VolVolume.hpp.

3.6.3 Member Function Documentation**3.6.3.1 int VOL_ivector::size() const [inline]**

Return the size of the vector.

Definition at line 270 of file VolVolume.hpp.

3.6.3.2 int& VOL_ivector::operator[](const int i) [inline]

Return a reference to the *i*-th entry.

Definition at line 272 of file VolVolume.hpp.

3.6.3.3 int VOL_ivector::operator[](const int i) const [inline]

Return the *i*-th entry.

Definition at line 278 of file VolVolume.hpp.

3.6.3.4 void VOL_ivector::clear() [inline]

Delete the content of the vector and replace it with a vector of length 0.

Definition at line 285 of file VolVolume.hpp.

3.6.3.5 void VOL_ivector::allocate(const int s) [inline]

delete the current vector and allocate space for a vector of size *s*.

Definition at line 293 of file VolVolume.hpp.

3.6.3.6 void VOL_ivector::swap (VOL_ivector & w) [inline]

swaps the vector with w.

Definition at line 300 of file VolVolume.hpp.

3.6.3.7 VOL_ivector& VOL_ivector::operator= (const VOL_ivector & v)

Copy w into the vector.

3.6.3.8 VOL_ivector& VOL_ivector::operator= (const int w)

Replace every entry in the vector with w.

3.6.4 Member Data Documentation

3.6.4.1 int* VOL_ivector::v

The array holding the vector.

Definition at line 245 of file VolVolume.hpp.

3.6.4.2 int VOL_ivector::sz

The size of the vector.

Definition at line 247 of file VolVolume.hpp.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.7 VOL_parms Struct Reference

This class contains the parameters controlling the Volume Algorithm.

```
#include <VolVolume.hpp>
```

Public Attributes

- double **lambdainit**
initial value of lambda
- double **alphainit**
initial value of alpha
- double **alphamin**
minimum value for alpha
- double **alphafactor**
when little progress is being done, we multiply alpha by alphafactor
- double **ubinit**
initial upper bound of the value of an integer solution
- double **primal_abs_precision**
accept if max abs viol is less than this
- double **gap_abs_precision**
accept if abs gap is less than this
- double **gap_rel_precision**
accept if rel gap is less than this
- double **granularity**
terminate if best_ub - lcost < granularity
- double **minimum_rel_ascent**
terminate if the relative increase in lcost through ascent_check_invl steps is less than this
- int **ascent_first_check**
when to check for sufficient relative ascent the first time
- int **ascent_check_invl**

through how many iterations does the relative ascent have to reach a minimum

- int **maxsgriters**
maximum number of iterations
- int **printflag**
controls the level of printing.
- int **printinvl**
controls how often do we print
- int **heurinvl**
controls how often we run the primal heuristic
- int **greentestinvl**
how many consecutive green iterations are allowed before changing lambda
- int **yellowtestinvl**
how many consecutive yellow iterations are allowed before changing lambda
- int **redtestinvl**
how many consecutive red iterations are allowed before changing lambda
- int **alphaint**
number of iterations before we check if alpha should be decreased
- char * **temp_dualfile**
name of file for saving dual solution

3.7.1 Detailed Description

This class contains the parameters controlling the Volume Algorithm.

Definition at line 71 of file VolVolume.hpp.

3.7.2 Member Data Documentation

3.7.2.1 int VOL_parms::printflag

controls the level of printing.

The flag should be the 'OR'-d value of the following options:

- 0 - print nothing
- 1 - print iteration information
- 2 - add lambda information
- 4 - add number of Red, Yellow, Green iterations

Default: 3


Definition at line 115 of file VolVolume.hpp.

The documentation for this struct was generated from the following file:

- VolVolume.hpp

3.8 VOL_primal Class Reference

Collaboration diagram for VOL_primal:



3.8.1 Detailed Description

Definition at line 313 of file VolVolume.hpp.

The documentation for this class was generated from the following file:


- VolVolume.hpp

3.9 VOL_problem Class Reference

This class holds every data for the Volume Algorithm and its `solve` method must be invoked to solve the problem.

```
#include <VolVolume.hpp>
```

Collaboration diagram for VOL_problem:



Public Member Functions

Constructors and destructor

- [VOL_problem \(\)](#)
Default constructor.
- [VOL_problem \(const char *filename\)](#)
Create a a `VOL_problem` object and read in the parameters from filename.
- [~VOL_problem \(\)](#)
Destruct the object.

Method to solve the problem.

- int **solve** (**VOL_user_hooks** &hooks, const bool use_preset_dual=false)
Solve the problem using the hooks.

Methods returning final data

- int **iter** () const
returns the iteration number
- double **alpha** () const
returns the value of alpha
- double **lambda** () const
returns the value of lambda

Public Attributes

- int **iter_**
iteration number

External data (containing the result after solve)

- double **value**
final lagrangian value (OUTPUT)
- **VOL_dvector dsol**
final dual solution (INPUT/OUTPUT)
- **VOL_dvector psol**
final primal solution (OUTPUT)
- **VOL_dvector viol**
violations ($b - Ax$) for the relaxed constraints

External data (may be changed by the user before calling solve)

- **VOL_parms parm**
The parameters controlling the Volume Algorithm (INPUT).
- int **psize**
length of primal solution (INPUT)

- int **dsize**
length of dual solution (INPUT)
- **VOL_dvector dual_lb**
lower bounds for the duals (if 0 length, then filled with -inf) (INPUT)
- **VOL_dvector dual_ub**
upper bounds for the duals (if 0 length, then filled with +inf) (INPUT)

3.9.1 Detailed Description

This class holds every data for the Volume Algorithm and its `solve` method must be invoked to solve the problem. The INPUT fields must be filled out completely before `solve` is invoked. `dsol` have to be filled out if and only if the last argument to `solve` is true.

Definition at line 605 of file VolVolume.hpp.

3.9.2 Constructor & Destructor Documentation

3.9.2.1 VOL_problem::VOL_problem()

Default constructor.

3.9.2.2 VOL_problem::VOL_problem(const char * *filename*)

Create a a `VOL_problem` object and read in the parameters from `filename`.

3.9.2.3 VOL_problem::~VOL_problem()

Destruct the object.

3.9.3 Member Function Documentation

3.9.3.1 int VOL_problem::solve(VOL_user_hooks & *hooks*, const bool *use_preset_dual = false*)

Solve the problem using the hooks.

Any information needed in the hooks must be stored in the structure `user_data` points to.

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.10 VOL.swing Class Reference

3.10.1 Detailed Description

Definition at line 390 of file VolVolume.hpp.

The documentation for this class was generated from the following file:


- VolVolume.hpp

3.11 VOL.user_hooks Class Reference

The user hooks should be overridden by the user to provide the problem specific routines for the volume algorithm.

```
#include <VolVolume.hpp>
```

Inheritance diagram for VOL_user_hooks:



Public Member Functions

- virtual int `compute_rc` (const `VOL_dvector` &u, `VOL_dvector` &rc)=0

compute reduced costs

- virtual int `solve_subproblem` (const `VOL_dvector` &`dual`, const `VOL_dvector` &`rc`, double &`lcost`, `VOL_dvector` &`x`, `VOL_dvector` &`v`, double &`pcost`)=0

Solve the subproblem for the subgradient step.

- virtual int `heuristics` (const `VOL_problem` &`p`, const `VOL_dvector` &`x`, double &`heur_val`)=0

Starting from the primal vector `x`, run a heuristic to produce an integer solution.

3.11.1 Detailed Description

The user hooks should be overridden by the user to provide the problem specific routines for the volume algorithm. The user should derive a class ...

for all hooks: return value of -1 means that volume should quit

Definition at line 563 of file VolVolume.hpp.

3.11.2 Member Function Documentation

3.11.2.1 virtual int VOL_user_hooks::compute_rc (const VOL_dvector & *u*, VOL_dvector & *rc*) [pure virtual]

compute reduced costs

Parameters

u (IN) the dual variables

rc (OUT) the reduced cost with respect to the dual values

3.11.2.2 virtual int VOL_user_hooks::solve_subproblem (const VOL_dvector & *dual*, const VOL_dvector & *rc*, double & *lcost*, VOL_dvector & *x*, VOL_dvector & *v*, double & *pcost*) [pure virtual]

Solve the subproblem for the subgradient step.

Parameters

dual (IN) the dual variables

rc (IN) the reduced cost with respect to the dual values
lcost (OUT) the lagrangean cost with respect to the dual values
x (OUT) the primal result of solving the subproblem
v (OUT) b-Ax for the relaxed constraints
pconst (OUT) the primal objective value of x

3.11.2.3 virtual int VOL_user_hooks::heuristics (const VOL_problem & p, const VOL_dvector & x, double & *heur_val*) [pure virtual]

Starting from the primal vector x, run a heuristic to produce an integer solution.

Parameters

x (IN) the primal vector
heur_val (OUT) the value of the integer solution (return DBL_MAX here if no feas
sol was found)

The documentation for this class was generated from the following file:

- VolVolume.hpp

3.12 VOL_vh Class Reference

3.12.1 Detailed Description

Definition at line 515 of file VolVolume.hpp.

The documentation for this class was generated from the following file:

- VolVolume.hpp

Index

~VOL_dvector
 VOL_dvector, 23

~VOL_ivector
 VOL_ivector, 27

~VOL_problem
 VOL_problem, 35

allocate
 VOL_dvector, 25
 VOL_ivector, 28

applyColCut
 OsiVolSolverInterface, 20

applyRowCut
 OsiVolSolverInterface, 20

assignProblem
 OsiVolSolverInterface, 18, 19

cc
 VOL_dvector, 24

clear
 VOL_dvector, 24
 VOL_ivector, 28

compute_rc
 VOL_user_hooks, 37

getDualRays
 OsiVolSolverInterface, 14

getEmptyWarmStart
 OsiVolSolverInterface, 13

getIterationCount
 OsiVolSolverInterface, 14

getPrimalRays
 OsiVolSolverInterface, 15

getRightHandSide
 OsiVolSolverInterface, 13

getRowRange
 OsiVolSolverInterface, 14

getRowSense
 OsiVolSolverInterface, 13

heuristics
 VOL_user_hooks, 38

loadProblem

OsiVolSolverInterface, 18, 19

operator=

- VOL_dvector, 25
- VOL_ivector, 29

OsiVolSolverInterface, 3

- applyColCut, 20
- applyRowCut, 20
- assignProblem, 18, 19
- getDualRays, 14
- getEmptyWarmStart, 13
- getIterationCount, 14
- getPrimalRays, 15
- getRightHandSide, 13
- getRowRange, 14
- getRowSense, 13
- loadProblem, 18, 19
- OsiVolSolverInterfaceUnitTest, 20
- setColLower, 15
- setColSetBounds, 15
- setColSolution, 17
- setColUpper, 15
- setRowLower, 16
- setRowPrice, 17
- setRowSetBounds, 16
- setRowSetTypes, 17
- setRowUpper, 16
- setWarmStart, 13
- writeMps, 20

OsiVolSolverInterfaceUnitTest
 OsiVolSolverInterface, 20

printflag
 VOL_parms, 31

setColLower
 OsiVolSolverInterface, 15

setColSetBounds
 OsiVolSolverInterface, 15

setColSolution
 OsiVolSolverInterface, 17

setColUpper
 OsiVolSolverInterface, 15

setRowLower
 OsiVolSolverInterface, 16
setRowPrice
 OsiVolSolverInterface, 17
setRowSetBounds
 OsiVolSolverInterface, 16
setRowSetTypes
 OsiVolSolverInterface, 17
setRowUpper
 OsiVolSolverInterface, 16
setWarmStart
 OsiVolSolverInterface, 13
size
 VOL_dvector, 24
 VOL_ivector, 28
solve
 VOL_problem, 35
solve_subproblem
 VOL_user_hooks, 37
swap
 VOL_dvector, 25
 VOL_ivector, 29
sz
 VOL_ivector, 29

v
 VOL_ivector, 29
VOL_alpha_factor, 21
VOL_dual, 21
VOL_dvector, 21
 ~VOL_dvector, 23
 allocate, 25
 cc, 24
 clear, 24
 operator=, 25
 size, 24
 swap, 25
 VOL_dvector, 23
 VOL_dvector, 23
VOL_indc, 25
VOL_ivector, 26
 ~VOL_ivector, 27
 allocate, 28
 clear, 28
 operator=, 29
 size, 28